

Category	Command	Phrases to say*
Call	Answer the call	Answer "Front door"
	Start two-way communication	Call "Front door"
ViP lock-release	Door opening	Unlock "Front door lock"
ViP actuator	Enable actuator	Unlock "Gate"
External unit camera	View external unit camera feed	Show "Front door"
Connected cameras	View connected cameras	Show "Sitting Room camera"